

80677

REPLACEMENT HANDLE BUTTONS

RESPUESTO BOTONS
PARA MANIJA

Replacement for PRICE PFISTER®
Reemplazo para PRICE PFISTER®



80677

REPLACEMENT HANDLE BUTTONS

RESPUESTO BOTONS PARA MANIJA

INSTRUCTIONS

TOOLS REQUIRED:

- 1. Pry off handle button (A) from faucet handle (B) with a small screwdriver.
- 2. Install replacement handle button (A) by pressing it into top of handle.

INSTRUCCIONES

HERRAMIENTAS REQUERIDAS:

- 1. Retire el botón de manija (A) de la manija del grifo (B) por apalancamiento con un destornillador pequeño.
- 2. Instale el botón de manija de repuesto (A) mediante presión al mismo sobre la parte superior de la manija.

Price Pfister® is a
registered trademark of
Stanley Black & Decker.



The Ace® Promise
If this Ace product, when used
for its intended purpose, fails to give
you complete satisfaction, return the
item to the Ace Hardware store where
you purchased for free replacement of
the same or similar item.

80677

Manufactured in China for
Fabricado en China para
Ace Hardware Corp.
Oak Brook, Illinois 60523
USA ©2014

www.acehardware.com

